



## Customer Instruction Guide

### Instructions for Touching Up Glaze Finish

#### Supplies Needed:

- Fine grit sanding pad (included)
- 1 clean tack rag (included)
- Safety Glasses (included)
- 1 spray-can of Clear Lacquer (**not included**—we recommend Pre-Catalyzed Clear, Aerosol Semi-Gloss from Mohawk finishing products or Clear Wood Finish Aerosol, Semi-Gloss Spray from The Home Depot)
- Glaze color sample block "A" (included).
- Oil based glaze product from local paint supplier.
- 1 small and one large paint brush.

#### Prepare the Surface

1. Wipe all rough areas with rubbing alcohol until they are free of all oils and/or cleaners.
2. Scuff the entire side molding with the sanding pad supplied.
  - Use light to moderate pressure.
  - Be careful not to sand the stained/painted finish off the area.
  - Area should feel smooth to the touch after sanding.
3. Remove all dust with clean tack rag.

#### Apply the Glaze

##### Doors, drawer fronts, false front & dentil molding (if applicable).

4. Apply a liberal amount of the glaze product to profile using the small brush.
  - Apply glaze in one even stroke across profile.
  - Repeat brush stroke with dry brush until desired color is achieved.
5. Wipe excess glaze off using clean towel.
6. Dry 1 hour.
  - Glaze must dry 1 hour to prevent peeling.

##### Side Molding

7. Brush the glaze on liberally using the large paint brush.
  - Apply glaze in one even stroke down side molding.
  - Repeat brush stroke with dry brush until desired color is achieved.
8. Wipe excess glaze off using clean towel.
9. Dry 1 hour.
  - Glaze must dry 1 hour to prevent peeling.

#### Apply the Lacquer

10. Shake lacquer spray can for at least one minute after the ball rattles.
  - Can temperature should be between 65 and 90 degrees Fahrenheit.
11. Hold the can 12 to 14 inches away from the part and spray a thin coat of lacquer to all areas.
  - Several thin coats work better than one heavy coat.
12. Apply lacquer with long, even strokes.
  - This prevents an uneven coat of lacquer.
13. Allow to dry for 2 hours before normal use.