



# Universal Sink Top Holder

## Installation Instructions

See separate instructions for Vanity Top Installation

### TOOLS AND SUPPLIES NEEDED

- ◆ Hammer
- ◆ Level
- ◆ Tape measure
- ◆ Phillips screwdriver
- ◆ Powered Drill and 3/16" Drill Bit
- ◆ Sabre/keyhole saw (may be needed if your vanity has a back)

### PREPARATION

Remove cabinet from carton. Remove old lavatory or vanity top. Check all old pipe fittings or get new ones before beginning the job.

### Attach Universal Sink Top Holder to Walls and side Cabinets if necessary.

Attach by screwing the back frame to the wall. It is necessary to drill holes in the back frame in order to attach them properly. At least one stud should be located and drilled with a mounting hole (see Figure 1). Use a level to make sure the Sink Top Holder is level and not more than 34" from the floor. Be sure to include the thickness of the counter top. Drill stud mount holes using 3/16" drill bit. Drill a 3/16" hole in wall for those general (non-stud) screw locations that are to be attached using plastic anchors. Then insert the plastic anchors in the wall. Attach to wall using the screws provided. Screw the Sink Top Holder into the side of the side cabinets to provide additional support. (See Figure 2)



Figure 1

### Notes:

- 1) Masonry walls require lead anchors to be set.
- 2) To Drill ceramic tile, first score the tile surface **gently** with a hammer and center punch or nail. Use a tungsten-carbide masonry drill bit only. To avoid breaking the tile, do not force the drill — allow it to cut through.

### Optional Accessibility Screen

This is mounted under the Sink Top Holder and directly in front of the P-Trap. Use the brackets provided to attach this screen. (See Figure 3) You will need to place a bracket at both ends, one at the top of the screen and one at the bottom.



Figure 2



Figure 3

Woodpro Cabinetry, Inc.  
Cabool, Missouri