



Pediment Installation Instructions

TOOLS AND SUPPLIES NEEDED

- ◆ Phillips Screwdriver
- ◆ Tape Measure

PREPARATION

Remove pediment from carton and remove bag of screws.

FIRST

Install the main cabinet that the Pediment will sit on using their enclosed Installation Instructions. Cabinets that a Pediment can be installed on are:

- Surface Mount Mirrored Cabinet
- Tri-View Mirrored Cabinet (non recessed)
- Framed Mirror
- Toilet Topper

NOTE:

If mirrored cabinet, framed mirror, tri-view or toilet topper has an attached crown molding assembly, then this assembly must be removed by removing the screws from the top of the cabinet.

SECOND

Center Pediment Over Cabinet

Assure that equal amounts of the Pediment overhang each side of the mirrored cabinet, framed mirror or toilet topper.

THIRD

Attach to Cabinet

Using the screws provided, attach the pediment to the top of the mirrored cabinet, framed mirror or toilet topper as shown at right.

