


Under Mount Drawer Box Adjustment


Installation on Vanity, Dresser, Linen or Counter Wall Cabinets

TOOLS AND SUPPLIES NEEDED

None



To remove the drawer, grip the orange handles (shown above) to release and pull drawer forward.



To adjust the drawer front, for level move this lever either to the front or to the back.



The soft close drawer glides have an adjustment on the back of each glide that can help adjust the vertical alignment of the drawer front. Move the lever (shown above) left or right to adjust. This will raise or lower the back of the drawer box.



Drawer Box AlignmentInstallation on Vanity, Dresser, Linen or Counter Wall Cabinets

TOOLS AND SUPPLIES NEEDED

None




To align the drawer front to be flush against the cabinet Drawer fronts have bumpers placed on back edge that will prevent drawer from laying flat against the frame.



This shows the back plugs out of alignment. This commonly happens from shipping.



Pull the drawer front out to the end of the glide. Push drawer to the right to adjust to left side. Push the drawer to the left to adjust to right side.



This shows the drawer plugs back in alignment after drawer was pulled out and properly re-aligned.