



Adjust a Drawer Side to Side

TOOLS AND SUPPLIES NEEDED

- Screwdriver
- Shims (provided)

1. Remove the drawer that is in need of adjustment
2. Remove the screw that holds the drawer glide on the side opposite the direction you need your drawer to move.
ie: If you need to move your drawer to the left remove the screw holding the right drawer glide as you are facing the cabinet.



3. Place one or more shims with the lip of the shim inside the cabinet and the screw hole centered in the slit of the shim.
 - a. If your drawer needs to move 1/32" use 1 shim. If it needs to move 1/16" use 2 shims.



4. Slide the drawer glide back into place and re-insert the screw carefully as not to strip the wood with the screw.
5. Re-install your drawer.
 - If your drawer needs to move more add another shim by repeating steps 1-4.

